

# A Series

## Installation, Operation & Maintenance Manual

**Project:** \_\_\_\_\_

**Installation:** \_\_\_\_\_

**Pump Model:** \_\_\_\_\_ **Serial Number:** \_\_\_\_\_

*AIOM REV. 6/14*

**HOMA Pump Technology, Inc.**  
390 Birmingham Boulevard • Ansonia, CT 06401

# A Series

## **GENERAL INSTRUCTIONS:**

This manual is intended to provide basic installation and start-up guidance. It is to be read and thoroughly studied prior to attempting to install or operate any of the equipment supplied. *Equipment damage, which occurs by not following these instructions will void the warranty.*

## **SAFETY PRECAUTIONS:**

*Only trained qualified personnel shall be utilized for installation and start-up.*

The following is a general list of safety precautions that should be followed when installing, starting-up or servicing the pump.

**The pump station owner or operator is ultimately responsible for ensuring that all equipment is installed, started up and operated in a safe manner.**

Do not work alone.

Double check to make sure that all lifting equipment is in good working order and that it has adequate lifting capacity for the weight that it will handle.

Wear safety helmet, goggles and protective shoes, or appropriate safety materials required.

Before working on the pump make sure that the power is disconnected and cannot be energized by others. Lockout and tag the control panel circuit breaker.

Do not stand under suspended loads!

Never enter or work within a wet well without first checking to make sure sufficient oxygen is present and that there are no explosive or poisonous gases present.

All personnel, who work with sewage pumping equipment and systems shall be vaccinated against diseases that can occur. If there are any questions or doubts in this area it is strongly suggested that the local health agency be contacted.

For Hazardous Area Classifications, only use pumps with suitable Explosion Proof Rating.

## **EQUIPMENT INVENTORY AND INSPECTION:**

Upon arrival of pump shipment carefully unpack all components and compare with shipping and purchase order documents to ensure that the order is complete. Also inspect equipment for any damage that might have occurred in shipment. *If any problems are detected contact an authorized HOMA Pump Technology Representative immediately.*

## **TRANSPORTATION AND STORAGE PROCEDURE:**

Always lift the pump by its lifting bail or eye bolt.

**Never lift the pump by its power cable!**

**Damage to Sealing ring or cable may result.**

Pumps should be stored in an upright position, taking extreme care to protect the power cable and control cables from crushing, nicks or tears which would permit water intrusion.

Power cable ends must be protected from immersion in water as well as moisture intrusion. The cable will wick water into the pump if it is not protected properly. Power cable leads should be covered with shrink tubing or suitable sealing material during storage.

**Short Term Storage:** Short term storage is defined as any time less than six months. We recommend that pump and accessories be stored in its original shipping container in a dry, temperature controlled area. If climate controlled storage is not possible, all exposed parts should be inspected before storage and all surfaces that have the paint scratched, damaged or worn should be re-coated with air dry enamel paint. The pump should be stored in an upright position.

**Long Term Storage:** Any storage time exceeding six months is considered long term. In addition to the safeguards specified above, the impeller should be rotated once a month to prevent the mechanical seals and bearings from being damaged, and the pump should be inspected. The seal chamber oil should be drained and replaced prior to commissioning. The pump should be stored in an upright position.

# A Series

## **ELECTRICAL INSTALLATION:**

### **GENERAL GUIDELINES**

All electrical work shall be carried out under the supervision of an authorized, licensed electrician.

**The present state adopted edition of the National Electrical Code as well as all local codes and regulations shall be complied with.**

### **VERIFICATION OF POWER SUPPLY**

Prior to making any electrical connections or applying power to the pump, compare the power supply available at the pump station to the data on the unit's nameplate. *Confirm that both voltage and phase match between pump and control panel.* The voltage supplied at the pump shall be +5 / -10% of the nameplate value, frequency shall be + / - 1% of the nameplate value, the voltage phase balance shall be within 1% and the maximum corrected power factor shall be 1.0.

**Voltage Change:** For instructions on changing the voltage of your stator, please consult the Technical Pages in the Downloads section of the HOMA website: [www.homapump.com](http://www.homapump.com).

### **POWER LEAD WIRING**

HOMA A Series pumps may be provided with 1 or more cables, depending on motor horsepower and operating voltage. Power leads L1, L2, & L3 may be provided as single conductor, or as multiple conductors. Multiple conductor configurations may use leads from separate cables, or may use two conductors within one cable. Please refer to enclosed wiring diagram for specific connection details. *The pump must be connected electrically through a motor starter with proper circuit breaker protection in order to validate warranty. Do not splice cables.*

### **THERMAL SWITCH WIRING :**

Pumps are equipped with thermal switches embedded in the stator windings which are normally closed, automatically resetting switches. Switches will open when the internal temperature rises above the design temperature, and will close when the temperature returns to normal. Thermal switches must be wired to a current regulated control circuit in accordance with the NEC.

Identify thermal switch leads marked T1 and T3 in the power or control cable.

The resistance across the leads will be .5 Ohms. Thermal leads must be connected to the thermal overload relay located in the control panel. *Thermal switch leads must be connected to validate warranty.*

**Note: All sizes of Class 1, Div. 1 pumps for hazardous service must have thermal switch leads connected to a current regulated control circuit in accordance with NEC.**

### **SEAL PROBE WIRING**

The mechanical seal leak detector probe utilized in the pump is a conductive probe which is normally open. The intrusion of water into the seal chamber completes the electrical circuit. Control panel provisions will sense this circuit closure, and will provide indication or alarm functions depending on the panel design.

Either single or dual wire systems may be provided. Single wire systems utilize one energizing conductor, and the pump casing and neutral lead as the ground or return portion of the circuit. The dual wire systems utilize two separate conductors for each leg of the circuit. With either system, the seal probe leads must be wired into a control circuit provided in the control panel. This control circuit must energize the probe with a regulated power source, and sense the closed circuit in event of water intrusion. Indication and alarm functions must also be provided in the control circuit. Please see control panel wiring diagram for seal probe connection points. *IMPORTANT: For Hazardous Area Classification Pumps, leak detector circuit must be in conformance with applicable NEC codes and regulations.*

### **START / RUN CAPACITORS AND RELAYS:**

All single phase motors require start and run capacitors along with a start relay to operate. Refer to the enclosed wiring diagram.

Capacitors and relays must be sized for the specific motor.

Capacitors are sized based on reference voltage. The run capacitor may need to be resized to match the available field voltage. Each cap kit shipped is supplied with a wiring diagram and start up procedure.

# A Series

## Variable Frequency Drives:

Special considerations must be taken when operating pumps with variable frequency drives (inverters). *The inverter circuit design, horsepower required by pump, motor cooling system, power cable length, operating voltage, and anticipated turndown ratio must be fully evaluated during the design stage of the installation.*

**As a minimum, properly sized load reactors and filters must be installed between the inverter and the pump to protect the pump motor from damaging voltage spikes.**

*Warranty coverage will not be provided on any pump motor that is operated with a variable frequency drive, unless the load side of the inverter is properly isolated from the pump.*

## ADDITIONAL PUMP PROTECTIVE DEVICES

Several optional pump protection devices are available to protect submersible motors from damage, and may be provided in your pump.

**Temperature Sensing RTD\***: PT100 sensors are available in two critical locations on larger machines, the lower bearings and motor windings. N.C. Circuit - 108 ohm

**Moisture Sensors**: In addition to the standard seal chamber probe, additional sensors may be installed in the stator winding, motor cap, or junction box. These sensors may be either one of the following:

**Moisture Detectors\***: These are micro float switches designed to detect small amounts of liquid. These are available in the stator housing of 50hp and larger size pumps. N.C. Circuit - 268 ohm

**Leakage Detectors\***: These normally open, single or 2 wire probes are used to detect the presence of water in the pump. *Single wire probes use the pump ground to complete circuit.*

\* HOMA Go Switch or approved equivalent relay is required for sensor operation.

## MECHANICAL INSTALLATION: PUMPS WITH AUTOCOUPLING SYSTEMS

The HOMA Auto-Coupling is a quick removal system used to prevent personnel from needing to enter the wet well.

The HOMA Auto-Coupling kit consists of a base, guide claw flange, upper guide rail bracket, profile seal. Refer to "Auto-Coupling Parts ID" technical page on website.

**For all A Series** pumps, attach the guide claw flange to the pump discharge flange with the fasteners and gaskets included with the auto-coupling kit. Use tightening torques indicated in the table on pg. 6. Do not over tighten! Install the profile gasket (if not already installed at the factory) into the guide claw with the large diameter fitted into the groove inside the claw. Refer to the attached instructional sheet for proper profile gasket installation.

Install suitable lifting chain of an adequate size and length to permit proper lowering and raising of the pump.

Properly locate the base, and with suitably sized anchor bolts, fasten it to the floor of the pump station. Make sure when locating and securing the anchor bolts that the base will align properly with the access cover at the top elevation of the station. Place the base in position, and level the base.

*If the base is not level, proper sealing of the pump to base may not occur!*

# A Series

Place the guide rails (supplied by others), cut to length into the rings of the base. The rails will be secured at the top of the pump station with the upper guide bar bracket and extend down to the sump floor.

Install the upper guide bar bracket to maintain vertical orientation of the guide rails.

*For stations exceeding 10 feet in depth intermediate guide bar brackets are recommended. One bracket is recommended for each additional 10 feet of station depth.*

Check that the guide system is properly installed in the vertical orientation by using levels and a plumb line. Fully tighten all anchors and mounting bolts.

Connect the station riser piping to the outlet flange of the base.

Before lowering the pump, verify the direction of impeller rotation (refer to technical details section for procedure).

**Make sure to use lifting equipment that has adequate capacity for the pump that will be handled.** Before installing pump, check to be certain the profile seal (rubber ring) is properly positioned in the guide claw flange. Then position pump so the guides on the discharge flange engage the rails. Slowly lower the pump along the guide rail. Once the pump reaches its bottom location it will automatically connect to the base.

*It is recommended that the stationary base elbow be visible before lowering the unit. If this is not possible, ensure all debris is removed from wet well.*

Important: Do not install more than one (1) check valve into any piping system or problems will occur.

## **Minimum Submergence**

For optimal cooling, motor should be completely submerged at all times. In pump-down systems, level should not fall below one discharge diameter above the top of the volute. For continuous operation with a VFD, level should not be maintained below the top of the motor for sustained periods. For specific inquiries, please contact factory for assistance.

## **INSTALLATION OF PUMPS WITH RING STANDS:**

The ring stand design allows for a free standing, simple economical installation or to be transportable from one installation to another. It is intended to operate completely or partially submerged in the pumping liquid.

Install the ring stand to the underside of the volute with the supplied fasteners provided. Apply thread locking compound such as blue #242 and tighten the bolts using the torque table indicated in the table. Do not over tighten! Install suitable lifting device of an adequate length to ensure proper lowering and raising capabilities. Lower the pump into the area where it is required. Properly position power cable and chain so they stay above pump and cannot enter the pump suction.

## **INSTALLATION OF PUMPS FOR DRY PIT APPLICATIONS:**

### **Foundation and Piping Requirements:**

#### General

The following recommendations are basic guidelines which are intended to outline basic requirements in the design of the dry pit station. It is essential that a licensed professional engineer be retained by the owner to design the station and all support structures.

#### Foundations

Foundations may consist of any structure heavy enough to provide permanent rigid support for the pump and inlet elbow stand. HI standards demand at least 5 times the weight of the pump. Concrete foundations built up from the solid ground are the most commonly used. The concrete floor shall be level. The space required by the inlet stand and the location of the foundation anchor bolts are shown on the outline dimension drawing. Foundation bolts are to be embedded in the concrete.



# A Series

## Suction Piping

Suction piping should be at least as large as the pump inlet elbow suction. If reducers are utilized they should be of the eccentric, conical type and must be installed with the level side up. Suction piping should be run as straight as possible with a recommended 10 suction diameter distance before pump inlet. Rough sections in pipe suction line can cause turbulence and result in severe vibration of the pump. Pipe reducers should not be installed adjacent to pump inlet

All pipe flange joints should be gasketed to prevent air from entering the pipe. High points that may collect vapor are to be avoided. Isolation valves such as gate valves can be installed in order to facilitate the removal of the pump for maintenance. Any valve installed in the suction line should be installed with the stems horizontal.

The location of the suction piping termination point inside of the wet pit must be installed such that sufficient submergence is obtained to prevent vortexing. Invert location and multiple suction points can cause hydraulic instability to an operating pump. Avoid high velocity or turbulence at suction pipe inlet.

## Discharge Piping

A check valve and isolation valve shall be installed in the discharge line. The check valve should be installed between the pump discharge flange and the isolation valve. If pipe increasers are used on the discharge line, they should be placed between the check valve and the pump. The inlet elbow stand allows the pump to be installed in a stationary position in a dry pit. Place the inlet stand in position and tighten the anchor nuts.

Lower the pump onto the top flange of the inlet stand. **DO NOT ALLOW SLACK ON THE LIFTING CABLE UNTIL THE PUMP IS BOLTED DOWN.** Make sure the flange bolt holes align with the mounting holes on the underside of the volute. Secure the pump to the mounting flange with the fasteners that are specified in the accessory fastener selection table below.

PUMP MODEL	Bolts Anchors	SIZE	TORQUE
<b>3" A SERIES AUTOCOUPLING</b>	8 4	M16X60mm M16	108 ft/ # 74 ft/ #
<b>4" A-SERIES AUTOCOUPLING</b>	8 4	M16X60mm M16	108 ft/ # 74 ft/ #
<b>3" &amp; 4" A-SERIES RING STAND</b>	4	M16x25mm	108 ft/#
<b>3" &amp; 4" A- SERIES DRY SUMP</b>	8 4	M16x40mm M16	108 ft/# 74 ft/#
<b>6" A-SERIES AUTOCOUPLING</b>	8 4	M20x70mm M16	150 ft/# 74 ft/#
<b>6" A-SERIES RING STAND</b>	4	M20x40mm	150 ft/#
<b>6" A-SERIES DRY SUMP (1 Piece)</b>	8 4	M20x45mm M16	150 ft/# 74 ft/#
<b>6" A-SERIES DRY SUMP (N/PMotor)</b>	8 4	M20x65mm M16	150 ft/# 74 ft/#
<b>6" A-SERIES DRY SUMP (F Motor)</b>	8 4	M20x70mm M16	150 ft/# 74 ft/#
<b>8" A-SERIES AUTOCOUPLING</b>	8 4	M20x70mm M20	150 ft/# 150 ft/#
<b>8" A-SERIES RING STAND</b>	4	M20x30mm	150 ft/#
<b>8" A-SERIES DRY SUMP (2 Piece)</b>	8 4	M20x75mm M20	150 ft/# 150 ft/#

### Notes:

1. For pumps larger than 8" please consult factory.
2. Flange bolts must be tightened in cross pattern to avoid damage to the raise face flanges.
3. Standard Flange Bolts are 316SS

# A Series

## Installation / Startup Troubleshooting:

*Only authorized service personnel who are trained professionals shall troubleshoot and repair pumps that are experiencing operational or performance difficulties.*

**All HOMA pumps are factory tested, yet startup difficulties can occur with any mechanical equipment. Please note that our technical support staff stands ready to assist you with any problem or difficulty you might encounter with our equipment.**

**The following is a tabulation of common start-up problems and possible causes.**

### Symptom

Possible Causes

#### Pump will not start

1, 2, 3, 4, 27, 28, 29, 31, 32

#### Little or zero discharge

5, 6, 7, 8, 16, 30, 32

#### Insufficient discharge flow/pressure

5, 6, 9, 10, 11, 12, 26, 30

#### Excessive power consumption

6, 9, 13, 28, 30

#### Excessive current draw

6, 13, 14, 15, 19, 26, 30

#### Excessive pump vibration/noise

12, 15, 16, 25, 26, 28, 31

#### Pump runs & motor protection trips

17, 18, 19, 20, 21, 28

#### Pump runs manually, but not automatically

22, 23, 24

#### Pump runs hot

7, 19, 25, 26, 28

## Listing of Possible Causes:

1. Incorrect or no power supplied to motor.
2. Power cable cut.
3. Short to ground in cable or motor winding.
4. Control panel circuit breaker open.
5. Actual system head is higher than calculated or specified.
6. Incorrect impeller rotation direction.
7. Sump liquid level is below pump's minimum submergence requirement.
8. Closed discharge valve or jammed check valve.
9. Wear ring worn. (If Applicable).
10. Vortex at pump's suction.
11. Discharge valve partially closed.
12. Insufficient NPSHA (Dry Pit Application).
13. Actual system head is lower than specified resulting in over pumping condition.
14. Voltage supply to motor is lower than required by motor.
15. Damaged bearings.
16. High system head causing pump to operate at extremely reduced capacity.
17. Object stuck inside impeller.
18. Motor not receiving proper voltage on all three phases.
19. Phase/currents unbalanced or too high.
20. Insulation between phases and earth ground, <1M-ohm.
21. Density of the pumping media too high.
22. Defective level sensor.
23. Hand/Off/Auto switch not in Auto Position.
24. Defective H/O/A switch, relay or contactor coil.
25. Air Captured in Cooling Jacket.
26. Pump not properly seated on Auto Coupling.
27. Water intrusion through junction box.
28. VFD or Soft Start not functioning properly.
29. Run capacitor size too large (1ph).
30. Start capacitor size too small (1ph).
31. Profile seal not sealing or missing.
32. Start relay or capacitor damaged (1ph).

Please note that some possible causes may not relate to your particular model.

---

**If you need additional help, please contact your local distributor or e-mail [service@homapump.com](mailto:service@homapump.com)**

# A Series

## **MAINTENANCE**

Regular maintenance will help ensure longer pump life and more reliable operation. It is recommended that pumps in intermittent operation be inspected twice a year and pumps in continuous operation be inspected every 1,000 hours. The following is a listing of required inspection and maintenance items.

**If any of the problems described in the following list exists stop operating the pump to avoid damage or personal injury.**

### **1. CABLE ENTRY**

Make sure that the cable entry flange and strain relief clamp are tight. If the cable entry is showing signs of leakage remove cable from entry, remove grommet, cut a piece of cable off so that the grommet seats on a new portion of the cable, replace grommet, and reinstall cable assembly, into the top of the motor.

*Note: Explosion Proof cables are sealed with a Factory Mutual Approved potting compound. Please consult factory for instruction.*

### **2. CABLES**

Inspect the cable for cuts, scrapes or sharp bends. If the outer jacket is damaged, replace the cable. Splices of the power or control cable within the wet well area are not acceptable.

### **3. MOTOR INSULATION RESISTANCE**

Megger the insulation between the phases; and between any phase and ground. Resistance values should be greater than 1 M ohm. If abnormal readings are obtained, contact authorized service center immediately.

### **4. EXTERNAL PARTS ON PUMP**

Make sure that all screws, bolts and nuts are tight. Check the condition of pump lifting eyes and replace if damaged or worn, Replace any external part that appears worn or damaged.

### **5. SEAL CHAMBER OIL**

*Note: Use extreme care when removing the seal chamber plug, as the chamber may become pressurized if seal failure has occurred.* Seal chamber oil should be checked for signs of water intrusion, or other impurities any time the pump is removed from wet well. To check the condition of the oil, remove the oil fill plug. Drain the chamber volume into a transparent container. Visually check sample for impurities or emulsification (oil may appear cream-like if a small amount of water is present). If significant water intrusion has occurred, remove and replace lower mechanical seal. Unless obvious mechanical damage has occurred to the lower seal, it is good practice to replace the upper and lower mechanical seals as a set. Refill seal chamber with fresh oil to the bottom of fill plug port (when pump is in vertical position) and replace oil fill plug.

### **6. IMPELLER**

Periodically inspect impeller by turning pump on its side, remove suction strainer nuts and strainer to expose impeller and relocate position of adjusting plate (suction cover) as needed. Replace the impeller if it is damaged or worn.

### **SPARE PARTS**

In order to obtain spare parts identify the required parts by looking at the enclosed cross sectional drawing and listing, and contact authorized HOMA PUMP TECHNOLOGY representative with your order. Authentic Homa Pump Technology parts shall be used to maintain warranty.

*Note: Explosion Proof pumps must be identified as such, and the pump serial number must be referenced for proper parts identification.*

### **RECOMMENDED TOOLS AND SUPPLIES**

In addition to ordinary maintenance and lifting devices, ensure that complete set of metric Allen wrenches, impeller puller, Loctite 242 (Blue), and Anti-seize compound are on hand.



# A Series

## Wire Markings of Power & Control Cables

Wire Marker	Wire Connection	Normal Value
<b>Power Cable (s)</b>		
L3	Power Supply	See Enclosed Wiring Diagram
L2	Power Supply	See Enclosed Wiring Diagram
L1	Power Supply	See Enclosed Wiring Diagram
Yellow/Green - Ground		
<b>Control Cable (s)</b>		
T1	Thermal Switch	N.C. .4 ohm
T2 or T3	Thermal Switch	N.C. .4 ohm
K1	Thermistor (optional)	N.C. 268 ohm
K2	Thermistor (optional)	N.C. 268 ohm
P1	Lower Bearing Temp. PT100	N.C. 108 ohm
P2	Lower Bearing Temp. PT100	N.C. 108 ohm
P3	Lower Bearing Temp. PT100	N.C. 108 ohm
P4	Lower Bearing Temp. PT100	N.C. 108 ohm
S1*	Oil Chamber Seal Probe	1 or 2 wire probe N.O.
S2	Oil Chamber Seal Probe	2 wire probe N.O.
S3	Connection Chamber Seal Probe	2 wire probe N.O.
S4	Connection Chamber Seal Probe	2 wire probe N.O.
S5*	Stator Housing Leak Detector	1 wire probe N.O.
S7	Stator Housing Leak Detector	Level Switch N.C. .7 ohm
S8	Stator Housing Leak Detector	Level Switch N.C. .7 ohm
Yellow/Green –Ground - *Must be used to complete 1 wire probe circuits!		

**Note: Pump may have single or multiple power or control cables. Verify all wire connections are correct before applying power to any circuit. Improper power supply can permanently damage certain control devices.**

**All control or monitoring devices must be connected to a suitable power supply and sensing device. Homa can provide an optional Go Switch for any of these control or monitoring devices. Consult your local Homa distributor**

## PROFILE SEAL INSTALLATION

When installing a profile seal, one side of the seal has a larger diameter ridge on the outside edge. This side goes to the inside of the guide claw as seen below.



Press the seal into its seat starting on one side and work the rest of the seal into the same position. When finished, it should look as below.



When properly installed, the profile seal will stay in place when pulled straight outwards.

It is recommended that 3M Weather Stripping be applied to the surface touching the claw if possible for added adhesion.

**REMEMBER:** the larger diameter always goes to the inside.

## Single Phase Pump Start-Up Procedure

Run Capacitor sizing can vary depending on the incoming supply voltage provided. HOMA Single Phase pumps are provided with Start and Run Capacitor(s) sized for 220-230V under load. Frequently, the available line voltage is considerably different than indicated, and the Run capacitor(s) may need to be resized to match the available field voltage. The following procedure will allow you to verify proper operation of your single phase pump, and/or make necessary changes to your capacitors to correct for your power supply.

After verifying wiring is in accordance with your pump requirements, start pump and record the following readings from each of the (3) pump cable leads.

### Current under load:

U1 \_\_\_\_\_ Amps, > U2 \_\_\_\_\_ Amps, > Z2 \_\_\_\_\_ Amps  
Should be (highest reading) (middle reading) (lowest reading)

Lead U1 (common) should have the highest current reading. Lead Z2 (start) should have the lowest reading.

If Z2 current draw is greater than the current draw of either U1 or U2, a smaller size Run capacitor (lower microfarad rating) is required to correct the condition. Example: If a 60  $\mu\text{f}$  Run capacitor was supplied, change to a 50  $\mu\text{f}$  Run capacitor and check current readings. Typically, only one step down in capacitor size is required, but in certain instances 2 steps may be required.

( ) The standard capacitor kit provided includes: \_\_\_\_\_  $\mu\text{f}$  start capacitor  
\_\_\_\_\_  $\mu\text{f}$  run capacitor.

( ) Additional run capacitors have been included for use in tuning the pump to match available line voltages for optimum performance.

\_\_\_\_\_  $\mu\text{f}$  run capacitor

\_\_\_\_\_  $\mu\text{f}$  run capacitor

\_\_\_\_\_  $\mu\text{f}$  run capacitor

This form is provided for your use in optimizing the performance and service life of your single phase pumps, and is applicable to most Capacitor Start/Capacitor Run motors. Please contact our Technical Service Department @ (203)-736-8890 with any questions or if you require any additional information or assistance.


## N Motor Capacitor Sizing Chart

Pump Model	Start Capacitor	Run Capacitor	Cap Kits
AMX334-434/1-142/2.9N	80µf @ 330V	40µf @ 370V	8857010
AMX334-434/1-155/4N	100µf @ 330V	50µf @ 370V	8857035
AMX334-434/1-178/4N	100µf @ 330V	50µf @ 370V	8857035
AMX334-434/1-184/5N	150µf @ 330V	80µf @ 370V	8857040
AMX334-434/1-193/5N	150µf @ 330V	80µf @ 370V	8857040
AMX334-434/1-193/7N	150µf @ 330V	100µf @ 370V†	8857045
AMX334-434/1-206/7N	150µf @ 330V	100µf @ 370V†	8857045
AMX334-434/1-206/10N	250µf @ 330V**	120µf @ 370V*	8857055
AMX334-434/1-218/10N	250µf @ 330V**	120µf @ 370V*	8857055
AMX334-434/1-228/10N	250µf @ 330V**	120µf @ 370V*	8857055

\* (2) 60µf run capacitors in parallel are required.  
 †(2) 50µf run capacitors in parallel are required.  
 \*\* (1) 150µf & 100µf start capacitor in parallel required.

\*Consult factory for A Frame motors with centrifugal switch.

## External Seal Probe Wiring



Seal Probes must be connected to a Homa Go Switch or suitable controller to operate.

## C, D & T Motor Capacitor Sizing Chart


Pump Model	Start Capacitor	Run Capacitor	Cap Kits
AMX334-434/1-1422/C/C	80µf @ 330V	40µf @ 370V	8807010
AMX334-434/1-142/2.5D	80µf @ 330V	50µf @ 370V	8857060
AMX334-434/1-142/2.9T/C	60µf @ 330V	40µf @ 370V	8857065
AMX334-434/1-155/3.6D	80µf @ 330V	50µf @ 370V	8857060
AMX334-434/1-155/4.3T/C	100µf @ 330V	50µf @ 370V	8857035
AMX334-434/1-155/5.1T/C	100µf @ 330V	50µf @ 370V	8857035
AMX334-434/1-178/3.6D	80µf @ 330V	50µf @ 370V	8857060
AMX334-434/1-178/4.3T/C	100µf @ 330V	50µf @ 370V	8857035
AMX334-434/1-178/5.1T/C	100µf @ 330V	50µf @ 370V	8857035
AMX334-434/1-184/5.1T/C	100µf @ 330V	50µf @ 370V	8857035
AMX334-434/1-193/5.1T/C	100µf @ 330V	50µf @ 370V	8857035
AMX334-434/1-193/6.7T/C	120µf @ 330V	60µf @ 370V	8857070
AMX334-434/1-206/6.7T/C	120µf @ 330V	60µf @ 370V	8857070
AMX334-434/1-206/9.7T/C	150µf @ 330V	80µf @ 370V	8857075
AMX334-434/1-218/9.7T/C	150µf @ 330V	80µf @ 370V	8857075
AMX334-434/1-228/9.7T/C	150µf @ 330V	80µf @ 370V	8857075
AMX334-434/1-228/11.4T/C	250µf @ 330V**	120µf @ 370V*	8857080
AMX334-434/1-235/11.4T/C	250µf @ 330V**	120µf @ 370V*	8857080
AMX334-434/1-250/11.4T/C	250µf @ 330V**	120µf @ 370V*	8857080

\* (2) 60µf run capacitors in parallel are required.

\*\* (1) 150µf & 100µf start capacitor in parallel required.

\*Consult factory for A Frame motors with centrifugal switch.

### External Seal Probe Wiring



Seal Probes must be connected to a Homa Go Switch or suitable controller to operate.



## START-UP REPORT

To validate warranty, please answer the following questions during start-up as completely and as accurately as possible and mail this form to:

**HOMA PUMP TECHNOLOGY, INC.  
390 BIRMINGHAM BOULEVARD  
ANSONIA, CT 06401  
ATTN: SERVICE MANAGER**

**Receipt of completed report will initiate operational warranty.  
Reports that are not returned can delay or void warranty.**

1.) Pump User's Name: \_\_\_\_\_  
Site Location: \_\_\_\_\_  
Site Contract: \_\_\_\_\_  
Unit Supplied By: \_\_\_\_\_

2.) HOMA Pumps Model \_\_\_\_\_ Serial No. \_\_\_\_\_  
Voltage \_\_\_\_\_ Phase \_\_\_\_\_ Hertz \_\_\_\_\_ Horsepower \_\_\_\_\_  
Method Used to Check Rotation (viewed from bottom) \_\_\_\_\_  
Does Impeller Turn Freely By Hand: YES \_\_\_\_\_ NO \_\_\_\_\_

3.) Condition of Equipment: EXCELLENT \_\_\_\_\_ GOOD \_\_\_\_\_ AVERAGE \_\_\_\_\_  
Condition of Cable Jacket : EXCELLENT \_\_\_\_\_ GOOD \_\_\_\_\_ AVERAGE \_\_\_\_\_  
Resistance of Cable and Pump Motor (measured at pump control)  
1 Phase: U1 – U2 \_\_\_\_\_ Ohms; U1 - Z2 \_\_\_\_\_ Ohms; U2 – Z2 \_\_\_\_\_ Ohms; T1 – T2 \_\_\_\_\_ Ohms  
3 Phase: U - V \_\_\_\_\_ Ohms; V - W \_\_\_\_\_ Ohms; U -W \_\_\_\_\_ Ohms, T1 – T2 \_\_\_\_\_ Ohms  
  
Resistance of Ground Circuit Between Control Panel and Outside of Pump \_\_\_\_\_ Ohms  
MEG Ohm Check of Insulation:  
U to Ground \_\_\_\_\_ V to Ground \_\_\_\_\_ W to Ground \_\_\_\_\_

4.) Condition of Equipment at Start-Up: Dry \_\_\_\_\_ Wet \_\_\_\_\_ Muddy \_\_\_\_\_ Was  
Equipment Stored: \_\_\_\_\_ Length of Storage \_\_\_\_\_  
Describe Station Layout \_\_\_\_\_

5.) Liquid Level Controls: Model \_\_\_\_\_ Type \_\_\_\_\_  
Is Control Installed Away From Turbulence? \_\_\_\_\_  
Operation Check: (IF FLOAT SWITCHES SUPPLIED).  
Tip lowest float (stop float), all pumps should remain off.  
Tip second float (and stop float), one pump comes on.  
Tip third float (and stop float), both pumps on (alarm on simplex).  
Tip fourth float (and stop float), high level alarm on (omit on simplex).

6.) Electrical Readings:

**Single Phase:**

Voltage Supply at Panel Line Connection, **Pump Off**, L1- L2 \_\_\_\_\_ L1-Ground \_\_\_\_\_ L2-Ground \_\_\_\_\_  
Voltage Supply at Panel Line Connection, **Pump On**, L1- L2 \_\_\_\_\_ L1-Ground \_\_\_\_\_ L2-Ground \_\_\_\_\_  
Amperage: Load Connection, **Pump On**, U1 \_\_\_\_\_ U2 \_\_\_\_\_ Z2 \_\_\_\_\_  
Resistance Across Thermal Switch leads T1-T2 \_\_\_\_\_ ohms

**Three Phase:**

Voltage Supply at Panel Line Connection, **Pump Off**, L1-L2 \_\_\_\_\_ L2-L3 \_\_\_\_\_ L3-L1 \_\_\_\_\_  
Voltage Supply at Panel Line Connection, **Pump On**, L1-L2 \_\_\_\_\_ L2-L3 \_\_\_\_\_ L3-L1 \_\_\_\_\_  
Amperage Load Connection, **Pump On**, L1 \_\_\_\_\_ L2 \_\_\_\_\_ L3 \_\_\_\_\_  
Resistance Across Thermal Switch leads T1-T2 \_\_\_\_\_ ohms

# A Series

7.) Starting Devices

Are pumps being started DOL, or with Soft Start device. Indicate manufacturer of Soft Starter. \_\_\_\_\_  
 Are any vibrations evident while pump is being controller by the soft starter? \_\_\_\_\_  
 Are pumps being operated with VFD (Variable Frequency Drive)? \_\_\_\_\_  
 Please indicate brand and model VFD: \_\_\_\_\_  
 Are load reactors being used between VFD output and pump? \_\_\_\_\_ Please indicate size \_\_\_\_\_  
 What ramp up and decel time is the VFD set for? Accel \_\_\_\_\_seconds, Decel: \_\_\_\_\_seconds  
 What is the minimum frequency the pump can operate at in this system? \_\_\_\_\_Hz. Is low speed limit set? \_\_\_\_\_

8.) Final Check:

Are Thermal Switches properly wired? \_\_\_\_\_ What Over-temperature Relay is being used? \_\_\_\_\_  
 Is Pump Seated On Discharge Properly? \_\_\_\_\_ Check For Leaks? \_\_\_\_\_  
 Does Check Valve Operate Properly? \_\_\_\_\_  
 Flow: Does Station Appear To Operate At Proper Rate \_\_\_\_\_  
 Vibration Level: Measured \_\_\_\_\_ Observed \_\_\_\_\_  
 Has the cooling jacket been vented? \_\_\_\_\_ Is a permanent cooling jacket vent installed? \_\_\_\_\_

COMMENTS: \_\_\_\_\_

9.) Equipment Difficulties During Start-Up: \_\_\_\_\_  
 \_\_\_\_\_  
 \_\_\_\_\_  
 \_\_\_\_\_

10.) I Certify this Report to be accurate.

Authorized Homa Service Representative:  
 \_\_\_\_\_ Phone # \_\_\_\_\_  
 (Signature)

DATE \_\_\_\_\_

Pump Station Owner/ Operator  
 \_\_\_\_\_ Phone # \_\_\_\_\_  
 (Signature)

DATE \_\_\_\_\_

## A Series Technical Details

The following is offered as a general guide to values and capacities commonly used.

HP / RPM	Resistance Readings (ohms)				Pump Weight Approx. (Lbs.)
	230V		230V	460V	
	1 Phase U1 - U2 / U1 - Z2		3 Phase * U-V-W	3 Phase * U-V-W	
2.5HP-1750 D	2.2	5.0	1.5	5.0	230 #
2.8HP-1160 T	N/A		2.7	5.0	230 #
2.9HP-1750 N	2.2	5.0	3.1	11.0	230 #
2.9HP-1750 T	1.6	4.4	3.1	11.0	230 #
3.5HP-1750 D	N/A		1.9	5.5	230 #
3.8HP-1160 T	N/A		1.5	2.5	240 #
4.3HP-1750 N	1.5	3.0	1.5	4.2	240 #
4.3HP-1750 T			1.5	4.2	240 #
5.1HP-1750 T	1.1	2.6	N/A	N/A	250 #
5.5HP-1750 N	0.9	1.9	1.3	3.7	250 #
5.5HP-1750 T	N/A		1.3	3.7	250 #
6.2HP-1160 T	N/A		1.3	3.7	250 #
6.7HP-1750 T	0.7	1.9	N/A	N/A	260 #
7.5HP-1750 N	0.8	1.5	0.9	2.6	260 #
7.5HP-1750 T	N/A		1.2	3.0	260 #
8.3HP-1160 T	N/A		0.9	2.6	260 #
9.7HP-1750 T	0.5	1.4	N/A	N/A	260 #
9.8HP-1160 P	N/A		0.7	2.2	290 #
10HP-1750 N	0.3	0.9	0.6	1.9	290 #
10HP-1750 T	N/A		0.6	1.9	290 #
11.4HP-1750 T	0.4	0.8	N/A	N/A	290 #
13HP-1750 P	N/A		0.5	1.8	350 #
15.3HP-1160 P	N/A		0.5	1.1	350 #
20HP-1750 P	N/A		0.5	1.1	400 #
21.5HP-1160 P	N/A		0.5	1.1	400 #
29HP-1750 P	N/A		0.4	0.7	500 #

\*Values should be as indicated between any 2 power leads.

Note: Resistance values include 30' cable, and should be within +/- 10% of above value.

Above 30 HP, resistance values between 230 and 460 volt machines vary by less than 0.1 ohm. Consult factory with specific requirements.

**Impeller Bolt Torque:** 10MM- 26FT#, 12MM-45FT#, 16MM-108FT#, 20MM- 210FT#

**Impeller to Bottom Plate Clearance: (ASC)** .020" minimum clearance.

**Pump Rotation** Right hand (CW) looking down from top of motor, CCW looking at bottom of pump.

**Seal Probes:** N motor pumps use a 12mm seal probe P motor pumps use 20mm seal probe. Single wire probes are for non classified areas, and 2 wire probes are for Hazardous areas.

## A Series Technical Details

Seal Chamber Oil: White Mineral Oil (Chevron Lubricating Oil FM 32, 46, 68)

### Seal Oil Volume

ALL N FRAME MOTORS                    2.5L

ALL T FRAME MOTORS                    2.5L

ALL P FRAME MOTORS                    3.7L

CURRENT D MOTORS                    0.9L

F, G & H FRAME SEAL OIL VOLUTE VARY BY HP, PLEASE CONSULT FACTORY WITH SPECIFIC PUMP MODEL.

### Seal Oil Level

With pump lying on its side and oil port at 12:00, measure from the top of housing with gasket in place, to the oil level.

A Series T, N & P motors:            1 1/2" from top of housing to oil level

### Minimum Distance between 2 pumps

	<b>3" Discharge</b>	<b>4" Discharge</b>	<b>6" Discharge</b>	<b>8" &amp; Larger</b>
<b>AK</b>	Min N/A	Min 10"	Min 13"	Please consult factory for lay- out information
<b>AV</b>	Min 8"	Min 10"	Min 13"	
<b>AMX</b>	Min 8"	Min 10"	Min 13"	