



Pump Troubleshooting: Electrical Malfunction

For pumps in service which have either tripped a breaker or have a high amp measurement, it is recommended the following be done on-site prior to pulling the pump.

- 1 Measure and record supply voltage and amp reading and compare to start-up information and recently collected data.
- 2 Measure and record data from operational pump in duplex station.
- 3 Perform Meg-Ohm test on site if possible to determine stator and power lead condition. If this test does not yield a short or open winding, proceed to the next step, # 4 below. If stator does not pass these electrical tests, then proceed to the following step, # 5 below.
- 4 If possible, switch power leads and determine if problem follows the pump. If problem stays with the supply, the pump is not causing the problem but may require inspection if operated for a long period with faulty supply,
- 5 If problem follows the pump, it is recommended the pump is pulled from service following all safety precautions as outlined in the applicable codes and instruction manuals and brought to a suitable shop for repair.

The following is a recommended outline of inspections to determine scope and nature of problem.

- 1 Visually inspect pump, cable and suction and discharge ports for any sign of problems. Proceed if there are no obvious problems.
- 2 If cable does not have noticeable cuts or abrasion, feel for signs of water intrusion. Cable will generally be slightly enlarged and will be more compressible or spongy. It is best to have a new cable on hand to compare with. If there are no signs of water, proceed to step 3. If there are signs of water skip to step 5.
- 3 Place the pump in a horizontal position and remove a small sample of seal oil. Take care not to spill any of oil. This oil should be clear and free of any signs of water or contaminants. If water is present, the oils will appear milky in color. If this oil is clean, proceed to step 5. The seal

oil will become contaminated with water under normal circumstances. If this occurs without any indication of stator problems, this oil can be changed and the pump placed back in service. If there are noted electrical problems as well as signs of water in the oil, it is likely the seals have become damaged and moisture has migrated up into stator. The pump will likely require a complete tear down. Proceed to step XX

- 4 If seal oil appears clean replace the plug and return pump to an upright position.
- 5 Remove top motor cap. For basic units, the top cap will expose the upper bearing and stator, whereas the explosion proof and units designed with a terminal board will have a secondary chamber. In either case inspect this area for signs of water intrusion and or stator damage. For the XP style, the second motor cap must be removed to inspect the stator. If there are any signs of water present proceed to step 6. If stator appears damaged, proceed to step 7.
- 6 The source of water must be determined. Explore each step below
 - a. If water is present in the chamber and the seal oil was clean, the power cord was the most likely source of water. Remove cable and inspect. Make a cut parallel to cable conductors and inspect the internal region of the cable. If water is present or there is a brownish residue, cable has been wet.
 - b. Inspect further to determine source of water. The grommet used to seal the cable at the entry point should be evenly compressed with no signs of wrinkling or uneven distortion. The point of contact of the cable and grommet should also be evenly compressed with no visible signs of uneven compression. If there are no signs of water entry at the cable entry and the seal oil is clean, the likely source of water is through the whole length of cable.
 - c. Further inspection of the cable will generally show signs of moisture throughout the entire cable. The installation site must now be inspected for possible causes of the water damage. "J" boxes in the wet well and improperly sealed control panels or junction boxes are likely sources of the water.
- 7 If the cause of the stator failure is not water damage and the seal oil is clean, there have been one or more electrical supply events that have occurred and caused damage. The cause of the problem must be determined, explore each step below. Further disassembly of the pump will be necessary for some of the inspections below.
- 8 Remove the power cables and perform the Meg-Ohm test again. If this test is OK, the power cables may be replaced and pump re-tested for service. If the stator fails the Meg Ohm test, further investigation of the stator is required. Continue with the steps below.
- 9 If the top of the stator looks in good condition with no general indication of excessive heat, inspect the interior portions of the stator for small signs of a burnt area. Small localized areas, in an asymmetrical

fashion in one location generally indicate a failure of the winding. If the pump is new and has operated for a period of less than 15 days, this is generally considered a warranty failure. Contact your local HOMA representative for additional information.

- 10 Large localized area in an asymmetrical fashion in one location generally indicates a power surge. This will discolor a large portion of a stator but not entirely. The cause of this failure needs to be determined.
- 11 If the stator is in generally good conditions with certain windings discolored and damaged in a symmetrical fashion this indicates a failure of the power supply. In a three phase motor, this will occur if there is a loss of one leg of power or if there is an unbalanced power supply. The site supply must be investigated to determine cause of failure and corrective action necessary to prevent further damage to the pump.
- 12 If the stator has all of the windings discolored and excessive heat is noted by melted winding ties, there has been an overload of the motor. Inspection of the bearing grease is necessary to determine if the pump was operating or if there was a locked rotor situation.
 - a. In an overheat situation where the pump was still able to run, inspection of the bearings would show the bearing grease turned into a dark, pasty consistency. Additionally in severe situations, the rotor would be melted and the aluminum would be flung away from the center of the rotor, this would indicate the pump had been over heating for an extended period. This can be caused by several operating conditions like a loss of cooling from inoperable float switches in a locked rotor situation. Proper installation of the motor thermals will limit the amount of damage to the pump.
 - b. In an overheat situation where the pump is not able to turn, the failure is usually quicker and bearing grease may not be affected. In this situation, the rotor will be heavily "blued" and the melted aluminum will have run down the rotor.