

GRP Lifting Handle

HOMA offers a choice of two separate autocoupling configurations. It is important to use the correct lift point, so that the pump will seat correctly. Both autocoupling configurations use a separate point identified below.



Autocoupling assembly number **8604018** uses an angled guideclaw (below). **Attach the tether through the circular hole in the rear tab of the lifting handle.**

Avoid retrieving pump by loop.
Only retrieve by the rear tab.
Retrieving by the central loop will cause pump to bind on rails.



Autocoupling assembly number **8604019** uses a straight guideclaw (below). **Attach the tether through the central loop of the lifting handle.**



Autocoupling assembly number **8604019** may be supplied with an optional, tall lifting handle, part number **8734104**. **Attach the tether through the central loop of the lifting handle.**

